FANUC ROBOSHOT &-S151B

Mechanical specifications

| mechanical specifications | | | | | | | | |
|---------------------------|---|---------------------------------|-------|-------------|-------------------------------|-----|-----|--|
| | Item | | | Unit | Data | | | |
| Clamping unit | Clamping mechanism | | | | Double toggle | | | |
| | Tonnage | | | kN | 150 (15tonf) | | | |
| | Maximum and minimum die height | | | mm | Double platen 260 - 130 | | | |
| | Clamping stroke | | | mm | 160 | | | |
| | Locating ring diameter | | | mm | φ60 | | | |
| | Tie bar spacing (H×V) | | | mm | 260 × 235 | | | |
| | Platen size (H×V) | | | mm | 355 × 340 | | | |
| | Minimum mold size (H×V) | | *1 | mm | 150 × 135 | | | |
| | Maximum mold weight (Moving-Stationary) | | *2 | kg | Double platen 60 - 60 | | | |
| | Ejector stroke | | | mm | 50 | | | |
| | Maximum ejector force | | | kN | 7 (0.7tonf) | | | |
| | Screw diameter | | | mm | 14 | 16 | 18 | |
| | Injection stroke | | | mm | 56 | 56 | 75 | |
| | Maximum injection volume | | *3 | cm³ | 9 | 11 | 19 | |
| ı | Inj.speed 800mm/s | Max. inj. prs.(W/C) | *4 *6 | MPa | 250 | 250 | 230 | |
| 5 | | Max. inj. prs.(General Purpose) | *4 *7 | MPa | 250 | 250 | 230 | |
| Injection unit | | Maximum injection rate | *5 | cm³/s | 123 | 160 | 203 | |
| 둉 | | Maximum injection speed | *5 | mm/s | 800 | | | |
| Jje | | Maximum screw rotation speed | | min⁻¹ | | 450 | | |
| I | Nozzle touch force | | kN | 5 (0.5tonf) | | | | |
| | Screw & Barrel | Number of pyrometers | | Barrel | 3 | | | |
| | | realiser of pyrometers | | Nozzle | 1 | | | |
| | | Total heater wattage | | kW | 2.5 | 2.9 | 3.2 | |
| | Machine Weight | | | t | Inj.speed 800mm/s Approx. 1.5 | | | |

- *1 Smaller mold than this size may limit clamp force.
- *2 If the weight of a mold exceeds maximum mold weight, the molding condition may be limited.
- The maximum injection volume is a calculated value. (Cross-sectional area x injection stroke)
- Maximum pack pressure is equal to maximum injection pressure. Maximum injection pressure and maximum pack pressure are the output of the injection unit, not the resin pressure. Maximum injection pressure and maximum pack pressure are the maximum values that can be set.
- Maximum injection rate and maximum injection speed is a theoretical value. Maximum injection rate and maximum injection speed can not be guaranteed when the injection pressure is maximum.
- Maximum injection pressure(W/C) are the values when the wear-resistant and anti-corrosion Barrel etc. is installed. Maximum injection pressure and maximum pack pressure may vary depends on the installed screw and Barrel specifications.
- Maximum injection pressure (General Purpose) are the values when the general purpose Barrel etc. is installed. Maximum injection pressure and maximum pack pressure may vary depends on the installed screw and Barrel specifications.
- The machine weight is the value when the option is not installed. Total weight may vary depending on equipment.
- The pressure conversion is 1MPa=10kgf/cm².
- *10 The molding condition might be limited by the resin.(Contact sales for detail)
- *11 In case of the replacement to different screw diameter after shipment, some covers may be needed to replace. (Contact sales for

Installation conditions

| | Item | Data | | |
|------------------|-------------------|---|--|--|
| T, | anut nower course | 3-phase AC200V±10% 50/60Hz±1Hz | | |
| 11 | nput power source | 3-phase AC220V±10% 60Hz±1Hz | | |
| Main breaker *12 | Inj.speed 800mm/s | 100A (With peripheral devices) *13 | | |
| Main breaker *** | | 50A (With no peripheral device) *13 | | |
| | Ground | Follow relevant laws and standards of the country where the | | |
| | Ground | machine is installed when performing grounding. | | |
| | Temperature | $0\sim40$ °C (20 \sim 25°C recommended) | | |
| Installing | Humidity | Below 75% (Below 95% under short term operation) | | |
| environment | Vibration | Below 0.5G | | |
| | Atmosphere | Take care of corrosive gas. | | |

- *12 Connect power cable to the machine's main breaker directly. The breaker is ground fault type with 100mA of sensitivity.
- *13 With peripheral devices: When the molding machine equiped "External outlet", "Mold heater controller" or "Integrated hotrunner controller". ("Mold heater controller" and "Intefrated hotrunner controller" cannot be selected simultaneously.) With no peripheral device: When only the molding machine is used.
- *14 Please contact sales for details about the value of sound generated in this machine.

FANUC ROBOSHOT @-\$15iB

